Imaging Sequences III

M219 - Principles and Applications of MRI Kyung Sung, Ph.D. 2/28/2024

Course Overview

- 2024 course schedule
 - https://mrrl.ucla.edu/pages/m219_2024
- Assignments
 - Homework #3 is due on 3/6
- Final exam
 - 3/18 at 2-4pm
- TA office hours, 2/28 4-5pm & 2/29 4-5pm
- Office hours, Thursday 10-12pm

Gradient Echoes & Fat


Chemical Shift - Type 1

- Fat and water have different Larmor frequencies
 - ~220Hz different at 1.5T
 - ~440Hz different at 3.0T
- Spatial position is related to spin frequency in MRI.
 - Fat is <u>more</u> spatially mis-registered @ 3T




Chemical Shift – Fat (–CH₂) is ~220Hz lower at 1.5T

Image Courtesy of Brian Hargreaves




Water Spins in a Uniform Field

Water spins precess at the same Larmor frequency in a uniform B₀ field.




Water Spins in a Gradient Field


Water spins precess at *different* Larmor frequencies in a non-uniform B₀ field.



Chemical (frequency) shift produces and apparent spatial shift.




GRE and Bandwidth




Higher bandwidths use stronger gradients and result in larger frequency differences along x. Chemical shift (frequency) is fixed for B_0 , therefore chemical shift (Δx) is a smaller percentage.

GRE and Bandwidth




GRE, Fat/Water & Bandwidth Low Bandwidth High Bandwidth



Acquisition *bandwidth* is related to the *speed* with which an echo is acquired. If the *bandwidth* (speed) is high, then there is less time for chemical shift, less time for signal acquisition (lower SNR), and a shorter TE/TR.

Chemical Shift - Type 2


- Pixels are frequently a mixture of fat and water
- Pixel intensity is the vector sum of fat and water




The TE controls the phase between fat and water.

GRE and Fat/Water Phase


In-Phase



Opposed-Phase




Dual-Echo Acquisition




In-phase and Out-of-phase


Example: 3 T abdominal scan




Out-of-phase (3 T), TE = 1.3 ms



In-phase (3 T), TE = 2.6 ms









2-Point Dixon


Example: 3 T abdominal scan



In-phase (3T), TE = 2.6 ms



Out-of-phase (3T), TE = 1.3 ms




Water


Gradient Echo – Summary

- Advantages
 - Fast Imaging Applications
 - Flexible contrast (T_1 or T_2^*)
- Disadvantages
 - Off-resonance sensitivity
 - T₂*-weighted rather than T₂-weighted


Spin Echo Imaging

Free Induction Decay






Record by computer.




Refocusing Pulses

- Typically, 180° RF Pulse
 - Provides optimally refocused M_{XY}
 - Largest spin echo signal
- Refocus spin dephasing due to
 - imaging gradients
 - local magnetic field inhomogeneity
 - magnetic susceptibility variation
 - chemical shift

Spin Echo - Refocusing



http://en.wikipedia.org/wiki/File:HahnEcho_GWM.gif



How do you adjust the TR? How do you adjust the TE?

Spin Echo Contrast

 $A_{Echo} \propto \rho \left(1 - e^{-TR/T_1} \right) e^{-TE/T_2}$

Longer TR minimizes T1 contrast Short TE minimizes T2 contrast

Intermediate TR maximizes T1 contrast Intermediate TE maximizes T2 contrast

Spin Echo Contrast

 $A_{Echo} \propto \rho \left(1 - e^{-TR/T_1} \right) e^{-TE/T_2}$


Longer TR minimizes T1 contrast Short TE minimizes T2 contrast


Intermediate TR maximizes T1 contrast Intermediate TE maximizes T2 contrast

Spin Echo Parameters


	ΤΕ	TR
Spin Density	Short	Long
T ₁ -Weighted	Short	Intermediate
T ₂ -Weighted	Intermediate	Long


Spin Echo Contrast







Spin Echo: TR=6500ms (ETL=12)







Spin Echo: TR=6500ms (ETL=12)



Spin Echo: TR=6500ms (ETL=12)


- Advantages
 - Insensitive to off-resonance
 - Re-focusing rephrases spin dephasing
 - Great for T_1 , T_2 , ρ contrast (not T_2^*)
 - High SNR
- Disadvantages
 - TR can be long
 - Leads to long scan time
 - SAR can be high
 - Lots of 90s and 180s lead to patient heating

Turbo Spin Echo (TSE) / Fast Spin Echo (FSE)


How do we calculate scan time?


$T_{Scan} = TR \cdot PE \cdot N_{avg}$

- T_{Scan}=1000ms•256•1=4:16 [mm:ss]
- Assumes one echo per TR.




Spin Echo





T₂-weighted TSE




Turbo Spin Echo vs. Spin Echo

Fast Spin Echo

Spin Echo


TR = 2500TE = 116ETL = 16NEX = 224 slices17 slices/pass2 passesTime = 2:51



TR = 2500TE = 112ETL = N/A NEX = 124 slices 20 slices/pass 2 passes Time = 22:21

Shorter scan time. More T2-weighted. Fat is brighter. Higher SAR.


Images: Courtesy Frank Korosec




PD vs T₂-weighted TSE

Proton Density Weighted

T₂-weighted






- Good cartilage signal
- Good cartilage/fluid contrast
- Late-Echo Blurring

Summary for TSE

- Pros:
 - Fast, high SNR
 - Less sensitive to B0 inhomogneity
- Cons:
 - T2 weighting varies in k-space
 - RF power limits speed, particularly at 3T
- Multi-echo acquisitions accelerate imaging, but single-shot methods (HASTE) are probably overkill

- 1. The 90-180 pair is the hallmark of the spin echo sequence
- 2. The 180 pulse is an inversion pulse.
- 3. Spin echoes are ultrafast sequences that provide T_1 or T_2^* weighted images.

- 1. The 90-180 pair is the hallmark of the spin echo sequence
- 2. The 180 pulse is an inversion pulse.
- 3. Spin echoes are ultrafast sequences that provide T_1 or T_2^* weighted images.



- 1. Long TE and long TR for T2-weighted
- 2. Short TE and short TR for T1-weighted
- 3. Spin echoes are low SAR sequences.

- 1. Long TE and long TR for T2-weighted
- 2. Short TE and short TR for T1-weighted
- 3. Spin echoes are low SAR sequences.


$$A_{Echo} \propto \rho \left(1 - e^{-TR/T_1} \right) e^{-TE/T_2}$$

Longer TR minimizes T1 contrast Short TE minimizes T2 contrast

Multi-Echo Imaging - True or False?

- 1. Multi-echo imaging can decrease scan times by 2x or more
- 2. Turbo spin echo is excellent for fast T2weighted imaging
- 3. Spin Echo EPI is routine for diffusion weighted imaging
- 4. Long TRs are important for T2 weighted imaging because they eliminate T1-contrast

Gradient vs. Spin Echo







Which image is a gradient echo image?

Images Courtesy of Brian Hargreaves

Gradient vs. Spin Echo





Both are T1-weighted Spin Echo has higher SNR (longer TR) GRE has shorter TE (meniscus/tendon is brighter)

Images Courtesy of Brian Hargreaves

Gradient echo imaging is great for everything except:

- A. T₂*-weighted imaging.
- B. T₂-weighted imaging.
- C. True 3D imaging.
- D. Real time imaging.

Gradient echo imaging is great for everything except:

A. T₂*-weighted imaging Yes. GRE can be a T₂*-weighted sequence.
B. T₂-weighted imaging No. GRE can not be T₂-weighted
C. True 3D imaging Yes! GRE is a fast sequence
D. Real time imaging Yes! GRE is a fast sequence

A. ... is great for T_2 imaging

B. ...works well for imaging near metal implants

C. ... is a fast acquisition technique

D. ...is insensitive to off-resonance effects

A. ...is great for T₂ imaging GRE is sensitive to T₂*, whereas SE is sensitive to T₂

B. ...works well for imaging near metal implants
 Metal causes large distortions for which SE is useful

C. ...is a fast acquisition technique

Yes! The TE/TR are typically quite short compared to SE

D. ...is insensitive to off-resonance effects.
 GRE is sensitive to B₀ inhomogeneity, chemical shift and susceptibility shifts

Gradient Echoes - True or False?

- 1. GRE sequences have longer TRs than SE sequences.
- 2. GRE is great for fast T1-weighted imaging.
- 3. Metal artifacts on GRE are typically small.
- 4. GRE is great for T2 contrast.

In Gradient Echo Imaging Always...

A. Use the highest available flip angle.

- B. Calculate and use the Ernst angle.
- C. Use a flip angle for maximum contrast.

In Gradient Echo Imaging Always...

A. Use the highest available flip angle.


B. Calculate and use the Ernst angle.

C. Use a flip angle for maximum contrast.

Gradient Echoes - True or False?


- 1. GRE and SE can both provide T2* contrast.
- 2. GRE and SE use the same TE and TR to produce a T1-weighted image.
- 3. SE is better for visualizing tissues with a very short T2 because of the refocusing pulses.
- 4. In GRE higher flip angles always produce brighter images.


Which image is the in-phase image?



Images Courtesy of Scott Reeder

Which image is the in-phase image?





In-Phase Opposed-Phase Images Courtesy of Scott Reeder

Gradient Echoes - True or False?

- 1. Fat and water precess at frequencies that are >1000Hz different.
- 2. Fat and water are always out of phase.
- 3. Fat and water destructively interfere when they are in phase.
- 4. In-flowing spins are bright because they "see" hundreds of excitation pulses.



- Related reading materials
 - Nishimura Chap 7

Kyung Sung, Ph.D. KSung@mednet.ucla.edu http://mrrl.ucla.edu/sunglab